



50-68-3105

MAZDASPEED 3 REAR WING EXTENSION

INSTALLATION INSTRUCTIONS

This part is made from OEM urethane. It is in raw-material form and should be painted.

1. Scuff the ENTIRE wing extension with 100-grit sandpaper, then coat with an etching urethane-type primer.
2. Sand and paint. NOTE: A qualified paint shop should know the proper preparation and finish.
3. Position the wing extension on the car. For the optimum fit, we suggest outlining the position with some masking tape.
4. Clean the wing surface thoroughly with alcohol or window cleaner in order to remove all wax or deposits. You can also prepare the tape area with 3M 94 Tape Primer.
5. Starting at one end, pull back the blue backing, and SLOWLY press the wing extension onto the car. NOTE: It takes 72 hours (3 days) for this tape to reach its full cure.